

# WIRING DIAGRAMS

## RiXeffects Digital High-Rez Boost Gauge

Follow the instructions and install video for removing your center console, and get some 20 gauge wire to use to extend the power, ground, and dimmer wires down to the ashtray area.

Hook the gauge wires to the extension wire, and then use tap-ins to tap the wires in the car as shown in the instructions and on these diagrams.

**IMPORTANT!** : If you had been running an earlier version gauge that required resistors for the dimmer line, remove all these and wire direct, as shown here.

